







Power Swap Controller Batteries

Batteries de Recharge pour Manettes

USE INSTRUCTIONS | UTILISATION

<p>1</p>	<p>CHARGE BATTERIES CHARGEZ LES BATTERIES</p> <p>Charge batteries for 10+ hours before first use Chargez les batteries pendant au moins 10 heures avant la première utilisation</p>	
<p>2</p>	<p>INSTALL CAGE + BATTERY INSTALLATION DE L'ÉTUI ET DE LA BATTERIE</p> <p>Select the cage that matches your controller (Xbox One or Xbox Series X S) Sélectionnez l'étui qui correspond à votre manette (Xbox One ou Xbox Series X S)</p>	 <p>The diagram shows two controller models at the top: Xbox Series X S on the left and Xbox One on the right. Below each model is a corresponding battery cage. Arrows point from the controller models to their respective cages.</p>
<p>3</p>	<p>Insert reserve energy cell into cage Insérez l'unité de charge de réserve dans l'étui</p> <p>Align rails. Push and click into place Alignez les rails. Obtenez le bon ajustement en effectuant une pression, jusqu'à entendre un clic</p>	 <p>The diagram shows a battery cage with a reserve energy cell being inserted into it. Arrows indicate the direction of insertion.</p>
<p>4</p>	<p>Remove controller battery plate Retirez le cache de batterie de la manette</p>	 <p>The diagram shows a controller with the battery plate being removed from the back. An arrow points upwards from the battery plate.</p>
<p>5</p>	<p>Remove any batteries Retirez la batterie</p>	 <p>The diagram shows two batteries being removed from the battery compartment.</p>
<p>6</p>	<p>Install cage into battery compartment Installez l'étui dans le compartiment batterie</p>	 <p>The diagram shows the battery cage being inserted into the battery compartment of the controller. An arrow points downwards from the cage.</p>
<p>7</p>	<p>Toe in battery and rotate to click into place Ajoutez la batterie et effectuez une rotation jusqu'à entendre un clic</p>	 <p>The diagram shows a battery being inserted into the battery compartment and rotated until it clicks into place. An arrow indicates the rotation.</p>

More product information | Plus d'information produit
otterbox.com/support

DE Weitere Produktinformationen IT Maggiori informazioni sul prodotto ES Más información del producto PT Mais informações sobre o produto JA 商品情報 KO 제품 세부 정보 ZHT 更多商品資訊 ZH 更多产品信息

20-56241_A